Refrigerator Replacement Rebate

Qualified Products List
- ENERGY STAR®
- 9+ cubic feet

Seattle City Light

Arctic King

Model	Configuration
ATMA100AEB	TF
ATMA100AES	TF
ATMA100AEW	TF
ATMA115AEB	TF
ATMA115AES	TF
ATMA115AEW	TF

Blomberg

Model	Configuration
BRFB1152SSN	BF
BRFB1452SSN	BF

Bosch

Model	Configuration
B11CB50SSS/01	BF
B30BB830SS	BF
B36BT830NS	BF

Crosley

Model	Configuration
CFD28SDQ*	BF
CFD28WIQ*	BF
CRT10PHS2	TF
CRT10PHW2	TF
CRT12PHS2	TF
CRT12PHW2	TF
CRT151HQ*	TF
CRT151HQ*	TF
CRT182HQ*	TF
CRT182HQ*	TF

Crosley

Model	Configuration
CRT186HQ*	TF
CRT186HQ*	TF
CRT206HQ*	TF
CRT206HQ*	TF

Dacor

Model	Configuration
RF36NDFSS*	BF

Danby

Model	Configuration
DFF092C1BSLDB	BF
DFF092C1WDB	BF

Danby Designer

Model	Configuration
DAR110A1*	RO
DFF100C2BSLDD	TF
DFF100C2WDD	TF

Electrolux

Model	Configuration
EI11BF25QS	BF
EI23BC30K**A	BF
EI23BC35K**A	BF
EI23BC60K**A	BF
EI23BC65K**A	BF
EI26SS30J**A	SS
EI28BS65K**A	BF

Emerald Cool

Model	Configuration
RF1802W	TF

Fagor

Model	Configuration
BMF-200X	BF

Fisher & Paykel

Model	Configuration
E522B******	BF
E522B******	BF
RF170W******	BF
RF170W******	BF
RF201A*****	BF
RF201A*****	BF

Frigidaire

Model	Configuration
DGHF2360P**A	BF
DGUS2645L**A	SS
FFED2322Q*	BF
FFEG2322Q*	BF
FFEN2822Q*	BF
FFET1022Q*	TF
FFET1222Q*	TF
FFEX2315Q*	SS
FFHB2740P**A	BF
FFHI1831Q*	TF
FFHI2131Q*	TF
FFHN2740P**A	BF
FFHT1514Q*	TF

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter

Frigidaire

Model	Configuration
FFHT1514Q*	TF
FFHT1521Q*	TF
FFHT1614Q*	TF
FFHT1614Q*	TF
FFHT1621Q*	TF
FFHT1621Q*	TF
FFHT1814Q*	TF
FFHT1814Q*	TF
FFHT1821Q*	TF
FFHT1821Q*	TF
FFHT1831Q*	TF
FFHT1831Q*	TF
FFHT2021Q*	TF
FFHT2021Q*	TF
FFHT2131Q*	TF
FFHT2131Q*	TF
FGEX2631Q*	SS
FGEX26D6Q**A	SS
FGHB2866P*	BF
FGHB2866P**A	BF
FGHF2366P**A	BF
FGHF2367Q*	BF
FGHG2366P**A	BF
FGHI1864Q*	TF
FGHI2164Q*	TF
FGHN2866P**A	BF
FGHS2355P**A	SS
FGHS2631P**A	SS
FGHS2655P**A	SS
FGHT1846Q*	TF
FGHT1846Q*	TF
FGHT2046Q*	TF
FGHT2046Q*	TF
FPHB2899P*	BF
FPHB2899P**A	BF
FPHF2399P*	BF

Frigidaire

Model	Configuration
FPHF2399P**A	BF
FPHG2399P**A	BF
FPHS2399P**A	SS
FPHS2699P**A	SS
LFHB2741P**A	BF
LFHT1831Q*	TF
LFHT1831Q*	TF
LFHT2131Q*	TF
LFHT2131Q*	TF
LGHB2867P*	BF
LGHB2867P**A	BF
LGHT1846Q*	TF
LGHT1846Q*	TF
LGHT2046Q*	TF
LGHT2046Q*	TF

Frigidiare

Model	Configuration
FFHT1521Q*	TF

Gaggenau

Model	Configuration
RB472701	BF
RB492701	BF
RC462701	RO
RC472701	RO
RY492701	BF

Gallery

Model	Configuration
FGVU17F8QF*	RO
FGVU17F8QT*	RO
FGVU17F8QW*	RO
FGVU21F8QF*	RO
FGVU21F8QT*	RO
FGVU21F8QW*	RO

GE

Model	Configuration
DFE28JGH****	BF
DFE28JMH****	BF
DFE28JSH****	BF
DSE25JGH****	SS
DSE25JMH****	SS
DSE25JSH****	SS
GDE20GGH****	BF
GDE20GMH****	BF
GDE20GSH****	BF
GDE23GGH****	BF
GDE23GSH****	BF
GFE28HGH****	BF
GFE28HMH****	BF
GFE28HSH****	BF
GIE16DGH****	TF
GIE16GSH****	TF
GIE18CTH****	TF
GIE18ETH****	TF
GIE18GCH****	TF
GIE18GSH****	TF
GIE18GTH****	TF
GIE18HGH****	TF
GIE18HSH****	TF
GIE18ISH****	TF
GIE21GSH****	TF
GIE21GTH****	TF
GNE29GGH****	BF
GNE29GMH****	BF
GNE29GSH****	BF
GPE16DTH****	TF
GPE16DTH****	TF
GSE22ESH****	SS
GSE22ETH****	SS
GSE25ESH****	SS
GSE25ETH****	SS
GSE25GGH****	SS

Qualified Refrigerator Models Seattle City Light

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter

GE

Model	Configuration
GSE25GSH****	SS
GSE25HGH****	SS
GSE25HMH****	SS
GSE25HSH****	SS
GTE15CTH****	TF
GTE15CTH****	TF
GTE15NTH****	TF
GTE15NTH****	TF
GTE16DTH****	TF
GTE16DTH****	TF
GTE16GSH****	TF
GTE16GSH****	TF
GTE16GTH****	TF
GTE16GTH****	TF
GTE18CCH****	TF
GTE18CTH****	TF
GTE18CTH****	TF
GTE18ETH****	TF
GTE18ETH****	TF
GTE18GMH****	TF
GTE18GMH****	TF
GTE18GSH****	TF
GTE18GSH****	TF
GTE18GTH****	TF
GTE18GTH****	TF
GTE18IGH****	TF
GTE18IGH****	TF
GTE18ISH****	TF
GTE18ISH****	TF
GTE18ITH****	TF
GTE18ITH****	TF
GTE18LGH****	TF
GTE18LGH****	TF
GTE18LMH****	TF
GTE18LMH****	TF
GTE18LSH****	TF

GE

Model	Configuration
GTE18LSH****	TF
GTE21GSH****	TF
GTE21GSH****	TF
GTE21GTH****	TF
GTE21GTH****	TF
GYE22KMH****	BF
GYE22KSH****	BF

GE Cafe

Model	Configuration
CFE28TSH****	BF
CWE23SSH****	BF
CYE22TSH****	BF

GE Monogram

Model	Configuration
ZIC30GNH****	BF
ZIC360NH****	BF
ZICP360NH****	BF
ZICS360NH****	BF
ZIR360NH****	RO
ZIRP360NH****	RO
ZIRS360NH****	RO

GE Profile

Model	Configuration
PFE28RSH****	BF
PSE25KGH****	SS
PSE25KSH****	SS
PWE23KGD****	BF
PWE23KMD****	BF
PWE23KSD****	BF
PYE22PSH****	BF

Haier

Model	Configuration
HT18TS78**	TF
HT21TS78**	TF

Hanover

Model	Configuration
HANRT10C*	TF
HANRT12C*	TF

Hisense

Model	Configuration
RB12N1ESE	BF
RB12N6PSE	BF
RB14N6ASE	BF
RB17N6ASE	BF
RD-46WC1H*	BF

Hotpoint

Model	Configuration
HPE15BTH****	TF
HPE15BTH****	TF

Ikea

Model	Configuration
IX3HHEXDS*	BF
IX6HHEXDS*	BF
IX7DDEXDS*	BF
IX7HHEXDS*	BF

Jenn-Air

Model	Configuration
JB36NXFXLE**	BF
JB36NXFXRE**	BF
JB36SSFX*A**	BF
JFC2089BE*	BF
JFX2597AE*	BF

Kenmore

Model	Configuration
253.7041*41	BF
2536011*41	TF
2536011*41	TF
2536031*41	TF
2536031*41	TF

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter

Kenmore

Model	Configuration
2536038*41	TF
2536038*41	TF
2536060*41	TF
2536060*41	TF
2536062*41	TF
2536062*41	TF
2537034*21	BF
2537034*41	BF
2537042*41	BF
2537044*21	BF
2537044*41	BF
2537060*41	TF
2537062*41	TF
2537063*41	TF
51823#	SS
6803#	TF
6935*	BF
6936*	BF
6938*	BF
7131#	BF
7132#	BF
7160#	BF
7248#	BF
7303#	BF
7305#	BF
7313#	BF
7401#	BF
7402#	BF
7403#	BF
7404#	BF
7405#	BF
7409#	BF
7803#	TF
7902#	BF
7904#	BF
7941*	BF

Kenmore

Model	Configuration
7942*	BF
7943#	TF
7946*	BF
970R4242*	TF
970R4242*	TF
970R4243*	TF
970R4243*	TF
970R4244*	TF
970R4244*	TF
970R4245*	TF
970R4245*	TF
970R4246*	TF
970R4246*	TF
970R7240*	BF
970R7242*	BF
970R7243*	BF

KFN 14943 SD

Model	Configuration
KFN 14943 SD	BF

KitchenAid

Model	Configuration
KB*S19KC*	BF
KB*S22KC*	BF
KBBR306EPA**	BF
KBBR306ESS**	BF
KBFN502EPA**	BF
KBFN502ESS**	BF
KBFS20EC*	BF
KBFS22EC*	BF
KBFS25EC*	BF
KBLC36FTS**	BF
KBLO36FTX**	BF
KBRC36FTS**	BF
KBRO36FTX**	BF
KBWG11NCSS	BF

KitchenAid

Model	Configuration
KFXS25RY*	BF
KSSC42QVS**	SS
KSSC48QVS**	SS

LG

Model	Configuration
LBC24360**	BF
LBN22370**	BF
LDC22370**	BF
LDC24370**	BF
LDN22470**	BF
LFC21776**	BF
LFC22770**	BF
LFC24770**	BF
LFC24786**	BF
LFC25776**	BF
LFC28768**	BF
LFCS31626*	BF
LFD22786**	BF
LFX21976**	BF
LFX28968**	BF
LFX29937**	BF
LFXC24726*	BF
LFXC24766*	BF
LFXS24623*	BF
LFXS24663*	BF
LFXS27566*	BF
LFXS29626*	BF
LFXS29766*	BF
LFXS30726*	BF
LFXS30766*	BF
LFXS32726*	BF
LFXS32766*	BF
LMXC23746*	BF
LMXS27626*	BF
LMXS30746*	BF

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter

LG

Model	Configuration
LMXS30776*	BF
LPXS30866*	BF
LSFD2491**	BF
LSSB2691**	SS
LSXS22423*	SS
LSXS26466*	SS
LTCS20220*	TF
LTCS24223*	TF

Liebherr

Model	Configuration
BF 1061	BF
CS 1200	BF
CS 1400	BF
CS 1611	BF
CS 1640	BF
CS 1660	BF
CS 2060	BF
CS 2061	BF
CS 2062	BF
HC 1000B	BF
HC 1001B	BF
HC 1030	BF
HC 1070	BF
HC 1540	BF
HC 1541	BF
HC 2060	BF
HC 2061	BF
HC 2062	BF
HCB 1560	BF
HCB 1561	BF
HCB 2060	BF
HCB 2061	BF
HCB 2062	BF
HRB 1120	RO
RB 1410	RO

Magic Chef

Model	Configuration
MCBM920B1	BF
MCBM920BE1	BF
MCBM920S1	BF
MCBM920W1	BF
MCBR920SE1	BF
MCBR920WE1	BF
MCR1010WEF	TF

Maytag

Model	Configuration
MB*1957DE*	BF
MBF1953DE*	BF
MBF1958DE*	BF
MBF2258DE*	BF
MFC2062DEM*	BF
MFF2258DE*	BF
MFF2558DE*	BF
MFT2574DE*	BF
MFT2776DE*	BF

MEILING

Model	Configuration
BCD-260WHA	BF
MRF-276W	BF
MRF-280WFA	TF

Midea

Model	Configuration
HD-366FWEN(SZ)	TF
HD-368RWE(SZ)	BF
HD-423FWEN(SZ)	TF
HD-663FWEN(SZ)	TF
HD-663W	TF
UR-BCD280WE-S	TF
UR-BCD326WE-S	TF

Miele

Model	Configuration
CIB30M1IR1	BF
CIB36M1IR1	BF
CIR30M1IR1	RO
CIR36M1IR1	RO
KFN 14943 SDE	BF
KFN 9855iDE	BF
KNF 12823 SD edt/cs-2	BF

Samsung

Model	Configuration
RF23HC*DB**	BF
RF23HC*DT**	BF
RF23HS*SB**	BF
RF23HT*DB**	BF
RF24FS*DB**	BF
RF25HM*DB**	BF
RF260B*AE**	BF
RF261BEAE**	BF
RF261BIAESR	BF
RF263B*AE**	BF
RF263T*AE**	BF
RF26HF*ND**	BF
RF26HFPNB**	BF
RF28HD*DB**	BF
RF28HD*DT**	BF
RF28HF*DT**	BF
RF28HFEDB**	BF
RF28HFPDB**	BF
RF28HM*DB**	BF
RF28HM*LB**	BF
RF30HB*DB**	BF
RF30HD*DT**	BF
RF31FM*DB**	BF
RF31FM*SB**	BF
RF323T*DB**	BF
RF32FM*DB**	BF

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter

Samsung

Model	Configuration
RF34H9950**	BF
RF34H9960**	BF
RH22H9010*	SS
RH29H9000**	SS
RL220N*TA**	BF
RL225N*TA**	BF
RS22HD*PN**	SS
RS25H5111**	SS
RS25H5121**	SS

Sub-Zero

Model	Configuration
BI-30U/*/**	BF
BI-36U/*/**	BF
IC-24R	RO
IC-30R**	RO
IT-30CI**	BF
IT-30R**	RO
IT-36CI**	BF
IT-36R**	RO

Summit

Model	Configuration
FFBF240WX	BF
FFBF280WX	BF

Thermador

Model	Configuration
T24IR800SP	RO
T30IB800SP	BF
T30IR800SP	RO
T36IB800SP	BF
T36IT800NP	BF

Whirlpool

Model	Configuration
WRB119WFB*	BF
WRB322DMB	BF

Whirlpool

Model	Configuration
WRB329*FB*	BF
WRB329DMB*	BF
WRB551WNBS	BF
WRF532SMB*	BF
WRF532SNB*	BF
WRF535SMB*	BF
WRF535SWB*	BF
WRF540CWB*	BF
WRF736SDA*	BF
WRS586FID*	SS
WRS586FLD*	SS
WRT134TFD*0*	TF
WRT138FZD*	TF
WRT148FZD*	TF
WRT541SZD*0*	TF
WRT549SZD*	TF

TF = Top Freezer BF = Bottom Freezer SS = Side-by-Side RO = Refrigerator Only SD = Refrigerator/Freezer Single Door

* = denotes arbitrary variable number/letter