

APPENDIX Q

ICC INTERNATIONAL RESIDENTIAL CODE ELECTRICAL PROVISIONS/NATIONAL ELECTRICAL CODE CROSS REFERENCE

(This appendix is informative and is not part of the code. This table is a cross reference of Chapters 34 through 43 of this code, and the 2011 *National Electrical Code, NFPA 70*).

International Residential Code

National Electrical Code

CHAPTER 34	GENERAL REQUIREMENTS	
SECTION E3401	GENERAL	
E3401.1	Applicability	None
E3401.2	Scope	90.2
E3401.3	Not covered.	90.2
E3401.4	Additions and alterations	None
SECTION E3402	BUILDING STRUCTURE PROTECTION	
E3402.1	Drilling and notching	None
E3402.2	Penetrations of fire-resistance-rated assemblies.	300.21
E3402.3	Penetrations of firestops and draftstops	300.21
SECTION E3403	INSPECTION AND APPROVAL	
E3403.1	Approval	110.2
E3403.2	Inspection required	None
E3403.3	Listing and labeling	110.3
SECTION E3404	GENERAL EQUIPMENT REQUIREMENTS	
E3404.1	Voltages	110.4
E3404.2	Interrupting rating.	110.9
E3404.3	Circuit characteristics	110.10
E3404.4	Enclosure types.	
E3404.5	Protection of equipment	110.11
E3404.6	Unused openings.	110.12(A)
E3404.7	Integrity of electrical equipment.	110.12(B)
E3404.8	Mounting	110.13(A)
E3404.9	Energized parts guarded against accidental contact	110.27(A)
E3404.10	Prevent physical damage	110.27(B)
E3404.11	Equipment identification	110.21
E3404.12	Identification of disconnecting means	110.22
SECTION E3405	EQUIPMENT LOCATION AND CLEARANCES	
E3405.1	Working space and clearances	110.26
Figure E3405.1	Working space and clearances	110.26(A)
	Footnote 1	110.26(E)(1)(a)
	Footnote 2	110.26(A)(3)
	Footnote 3	110.26(B)
	Footnote 4	230.70(A); 240.24(D), (E) and (F); Note 5
	Footnote 5	110.26(D)
E3405.2	Working clearances for energized equipment and panelboards.	110.26(A)(1), (2) and (3)

APPENDIX Q

E3405.3 Dedicated panelboard space 110.26(F)(1)(a)
E3405.4 Location of working spaces and equipment 110.26(B); 230.70(A); and
240.24(D), (E) and (F)
E3405.5 Access and entrance to working space 110.26(C)(1)
E3405.6 Illumination 110.26(D)

SECTION E3406 ELECTRICAL CONDUCTORS AND CONNECTIONS

E3406.1 General Articles 110, 300 and 310
E3406.2 Conductor material 110.5
E3406.3 Minimum size of conductors 310.106(A)
E3406.4 Stranded conductors 310.106(C)
E3406.5 Individual conductor insulation 310.10(B) and (C); and 310.106(D)
E3406.6 Conductors in parallel 310.10(H)(2)
E3406.7 Conductors of the same circuit 300.3(B)
E3406.8 Aluminum and copper connections 110.14
E3406.9 Fine stranded conductors 110.14
Table E3406.9 Conductor stranding Chapter 9, Table 10
E3406.10 Terminals 110.14(A)
E3406.11 Splices 110.14(B)
E3406.11.1 Continuity 300.13(A)
Exception 300.13(A)
E3406.11.2 Device connections 250.148(B) and 300.13(B)
E3406.11.3 Length of conductor for splice or termination 300.14
E3406.12 Grounded conductor continuity 200.2(B)

SECTION E3407 CONDUCTOR IDENTIFICATION

E3407.1 Grounded conductors 200.6(A) and (B); and 310.110(A)
E3407.2 Equipment grounding conductors 250.119 and 310.110(B)
E3407.3 Ungrounded conductors 200.7(C)(1) and 310.110(C), Exception
E3407.4 Identification of terminals 200.10
E3407.4.1 Device terminals 200.10(A)
E3407.4.2 Receptacles, plugs and connectors 200.10(B)

CHAPTER 35 ELECTRICAL DEFINITIONS

SECTION 3501 GENERAL Article 100, Definitions

CHAPTER 36 SERVICES

SECTION E3601 GENERAL SERVICES

E3601.1 Scope 230.1
E3601.2 Number of services 230.2
E3601.3 One building or other structure not to be supplied through another 230.3
E3601.4 Other conductors in raceway or cable 230.7
E3601.5 Raceway seal 230.8
E3601.6 Service disconnect required 230.70
E3601.6.1 Marking of service equipment and disconnects 230.66 and 230.70(B)
E3601.6.2 Service disconnect location 230.70(A) and 230.72(C)
E3601.7 Maximum number of disconnects 230.71(A)

SECTION E3602	SERVICE SIZE AND RATING	
E3602.1	Ampacity of ungrounded conductors	230.79(C) and (D)
E3602.2	Service load	220.82(A)
Table E3602.2	Minimum service load calculation	220.82(B) and (C)
E3602.2.1	Services under 100 amperes	None
E3602.3	Rating of service disconnect.	230.79 and 230.80
E3602.4	Voltage rating	220.82(A)
SECTION E3603	SERVICE, FEEDER AND GROUNDING ELECTRODE CONDUCTOR SIZING	
E3603.1	Grounded and ungrounded service conductor size	310.15(B)(7)
Table E3603.1	Service conductor and grounding electrode conductor sizing	Table 310.15(B)(7) and Table 250.66
	Footnote a	250.64(E)
	Footnote b	250.64(B)
	Footnote c	250.64(B)
	Footnote d	250.66(A) and (B)
E3603.2	Ungrounded service conductors for accessory buildings and structures	230.79(D)
	Exception 1	230.42 and 230.79(A)
	Exception 2	230.42 and 230.79(B)
E3603.3	Overload protection	230.90
E3603.3.1	Ungrounded conductor	230.90(A)
	Exception	230.90(A), Exception 3
E3603.3.2	Not in grounded conductor	230.90(B)
E3603.3.3	Location	230.91
E3603.4	Grounding electrode conductor size	250.66
E3603.5	Temperature limitations	110.14(C)(1)
SECTION E3604	OVERHEAD SERVICE AND SERVICE-ENTRANCE CONDUCTOR INSTALLATION	
E3604.1	Clearances on buildings	230.9
Figure E3604.1	Clearances from building openings	230.9
E3604.2	Vertical clearances	230.24
E3604.2.1	Above roofs	230.24(A)
	Exception 1	230.24(A), Exception 1
	Exception 2	230.24(A), Exception 2
	Exception 3	230.24(A), Exception 3
	Exception 4	230.24(A), Exception 4
	Exception 5	230.24(A), Exception 5
Figure E3604.2.1	Clearances from roofs.	230.24
E3604.2.2	Vertical clearance from grade.	230.24(B)
	Item 1	230.24(B)(1)
	Item 2	230.24(B)(2)
	Item 3	230.24(B)(4)
E3604.3	Point of attachment.	230.26
E3604.4	Means of attachment.	230.27
E3604.5	Service masts as supports	230.28
E3604.6	Supports over buildings	230.29

SECTION E3605

SERVICE-ENTRANCE CONDUCTORS

E3605.1	Insulation of service-entrance conductors	230.41
	Exception 1	230.41, Exception
	Exception 2	230.41, Exception
E3605.2	Wiring methods for services	230.43
E3605.3	Spliced conductors	230.46
E3605.4	Protection of underground service entrance conductors	230.50(A)
E3605.5	Protection of service cables against damage	230.50(B)
E3605.6	Direct sunlight exposure	310.10(D)
E3605.7	Mounting supports	230.51
E3605.8	Raceways to drain	230.53
E3605.9	Overhead service locations	230.54
E3605.9.1	Rain-tight service head	230.54(A)
E3605.9.2	Service cable, service head or gooseneck	230.54(B)
E3605.9.3	Service head location	230.54(C)
	Exception	230.54(C), Exception
E3605.9.4	Separately bushed openings	230.54(E)
E3605.9.5	Drip loops	230.54(F)
E3605.9.6	Conductor arrangement	230.54(G)
E3605.9.7	Secured	230.54(D)

SECTION E3606

SERVICE EQUIPMENT—GENERAL

E3606.1	Service equipment enclosures	230.62
E3606.2	Working space	110.26
E3606.3	Available short-circuit current	110.9
E3606.4	Marking	230.66

SECTION E3607

SYSTEM GROUNDING

E3607.1	System service ground	250.20(B)(1) and 250.24(A)
E3607.2	Location of grounding electrode conductor connection	250.24(A)(1) and (A)(5)
E3607.3	Buildings or structures supplied by feeder(s) or branch circuit(s)	250.32(A)
	Exception	250.32(A), Exception
E3607.3.1	Equipment grounding conductor	250.32(B) and Table 250.122
E3607.3.2	Grounded conductor	250.32(B)(1), Exception
E3607.4	Grounding electrode conductor	250.24(D)
E3607.5	Main bonding jumper	250.24(B)
E3607.6	Common grounding electrode	250.58

SECTION E3608

GROUNDING ELECTRODE SYSTEM

E3608.1	Grounding electrode system	250.50
	Exception	250.50, Exception
E3608.1.1	Metal underground water pipe	250.52(A)(1)
E3608.1.1.1	Interior metal water piping	250.68(C)(1)
E3608.1.1.2	Installation	250.53(D) and 250.53(E)
E3608.1.2	Concrete-encased electrode	250.52(A)(3)
E3608.1.3	Ground rings	250.52(A)(4) and 250.53(F)
E3608.1.4	Rod and pipe electrodes	250.52(A)(5)

E3608.1.4.1	Installation	250.53(G)
E3608.1.5	Plate electrodes	250.52(A)(7) and 250.53(H)
E3608.1.6	Other listed electrodes	250.52(A)(6)
E3608.2	Bonding jumper	250.53(C)
E3608.3	Rod, pipe and plate electrode requirements	250.53(A), (B) and (E)
E3608.4	Supplemental electrode required	250.53(A)(2) and (A)(3)
E3608.5	Aluminum electrodes	250.52(B)(2)
E3608.6	Metal underground gas piping system	250.52(B)(1)
SECTION E3609	BONDING	
E3609.1	General	250.90
E3609.2	Bonding of service equipment	250.92(A)
E3609.3	Bonding to other systems	250.94
E3609.4	Method of bonding at the service	250.92(B)
E3609.4.1	Grounded service conductor	250.92(B)(1)
E3609.4.2	Threaded connections	250.92(B)(2)
E3609.4.3	Threadless couplings and connectors	250.92(B)(3)
E3609.4.4	Other devices	250.92(B)(4)
E3609.5	Sizing bonding jumper on supply side of service and main bonding jumper	250.28(D) and 250.102(C)
E3609.6	Metal water piping bonding	250.104(A)
E3609.7	Bonding other metal piping	250.104(B)
SECTION E3610	GROUNDING ELECTRODE CONDUCTORS	
E3610.1	Continuous	250.64(C) and (F)
E3610.2	Securing and protection against physical damage	250.64(A) and (B)
E3610.3	Enclosures for grounding electrode conductors	250.64(E)
E3610.4	Prohibited use	250.121
SECTION E3611	GROUNDING ELECTRODE CONDUCTOR CONNECTION TO GROUNDING ELECTRODES	
E3611.1	Methods of grounding connection to electrodes	250.70
E3611.2	Accessibility	250.68(A)
E3611.3	Effective grounding path	250.68(B)
E3611.4	Interior metal water piping	250.68(C)(1)
E3611.5	Protection of ground clamps and fittings	250.10
E3611.6	Clean surfaces	250.12
CHAPTER 37	BRANCH-CIRCUIT AND FEEDER REQUIREMENTS	
SECTION E3701	GENERAL	
E3701.1	Scope	None
E3701.2	Branch-circuit and feeder ampacity	210.19(A) and 215.2(A)(1)
E3701.3	Selection of ampacity	310.15(A)(2), Exception
E3701.4	Branch circuits with more than one receptacle	210.19(A)(2)
E3701.5	Multiwire branch circuits	210.4
E3701.5.1	Disconnecting means	210.4(B)
E3701.5.2	Grouping	210.4(D)

SECTION E3702

E3702.1	Branch-circuit voltage limitations	210.6(A), (B) and (C)
E3702.2	Branch-circuit ampere rating	210.3
E3702.3	Fifteen- and 20-ampere branch circuits	210.23(A)
E3702.4	Thirty-ampere branch circuits	210.23(B)
E3702.5	Branch circuits serving multiple loads or outlets	210.23(A)
E3702.6	Branch circuits serving a single motor	430.22(A)
E3702.7	Branch circuits serving motor-operated and combination loads	220.18(A)
E3702.8	Branch-circuit inductive lighting loads	220.18(B)
E3702.9	Branch-circuit load for ranges and cooking appliances	Table 220.55, Note 4
E3702.9.1	Minimum branch circuit for ranges	210.19(A)(3)
E3702.10	Branch circuits serving heating loads	422.13; and 424.3(A) and (B)
E3702.11	Branch circuits for air-conditioning and heat pump equipment	440.4(B), 440.35 and 440.62(A)
E3702.12	Branch circuits serving room air conditioners	440.62(A)
E3702.12.1	Where no other loads are supplied	440.62(B)
E3702.12.2	Where lighting units or other appliances are also supplied	440.62(C)
E3702.13	Branch-circuit requirement—summary	210.24 and 210.25
Table E3702.13	Branch-circuit requirement—summary	Table 210.24

SECTION E3703

E3703.1	Branch circuits for heating	422.12 and 422.12, Exceptions 1 and 2
E3703.2	Kitchen and dining area receptacles	210.52 (B)(1)
E3703.3	Laundry circuit	210.11(C)(2); and 210.23(A), Exception
E3703.4	Bathroom branch circuits	210.11(C)(3)
E3703.5	Number of branch circuits	210.11(A)
E3703.6	Branch-circuit load proportioning	210.11(B)

SECTION E3704

E3704.1	Conductor size	215.2 (A)(3) and (A)(4); 220.40; and Table 310.15(B)(7)
E3704.2	Feeder loads	220.40
Table E3704.2(1)	Feeder load calculation	Table 220.12, 220.14, Table 220.42(C), 220.50, 220.51, 220.52, 220.53, 220.54, 220.55 and 220.60
Table E3704.2(2)	Demand loads for electric ranges, wall-mounted ovens, counter-mounted cooking units and other cooking appliances over 13/4 kVA rating	Table 220.55
E3704.3	Feeder neutral load	220.61
E3704.4	Lighting and general use receptacle load	220.12, Table 220.12 and 220.14(J)
E3704.5	Ampacity and calculated loads	220.40
E3704.6	Equipment grounding conductor	215.6

SECTION E3705

E3705.1	General	310.15(A)
Table E3705.1	Allowable ampacities	Table 310.15(B)(16)
E3705.2	Correction factors for ambient temperatures	Table 310.15(B)(16)
Table E3705.2	Ambient temperature correction factors	Table 310.15(B)(2)(a)
E3705.3	Adjustment factor for conductor proximity	310.15(B)(3)(a)
Table E3705.3	Conductor proximity adjustment factors	Table 310.15(B)(3)(a)
E3705.4	Temperature limitations	110.14(C)

BRANCH-CIRCUIT RATINGS

REQUIRED BRANCH CIRCUITS

FEEDER REQUIREMENTS

CONDUCTOR SIZING AND OVERCURRENT PROTECTION

E3705.4.1	Conductors rated 60°C.....	110.14(C)(1)(a)
E3705.4.2	Conductors rated 75°C.....	110.14(C)(1)(b)
E3705.4.3	Separately installed pressure connectors	110.14(C)(2)
E3705.4.4	Conductors of Type NM cable	334.80 and 334.112
E3705.5	Overcurrent protection required	240.4, 240.21 and Table 310.15(B)(6)
E3705.5.1	Cords	240.5
E3705.5.2	Overcurrent devices of the next higher size	240.4(B)
E3705.5.3	Small conductors	240.4(D)
E3705.5.4	Air-conditioning and heat pump equipment	240.4(G)
E3705.6	Fuses and fixed-trip circuit breakers	240.6
E3705.7	Location of overcurrent devices in or on premises	240.24(A), (C), (D), (E) and (F)
E3705.8	Ready access for occupants	240.24(B)
E3705.9	Enclosures for overcurrent devices	240.30(A) and (B)
SECTION E3706	PANELBOARDS	
E3706.1	Panelboard rating	408.30
E3706.2	Panelboard circuit identification	408.4
E3706.3	Panelboard overcurrent protection	408.36
E3706.4	Grounded conductor terminations	408.41
E3706.5	Back-fed devices	408.36(D)
CHAPTER 38	WIRING METHODS	
SECTION E3801	GENERAL REQUIREMENTS	
E3801.1	Scope	300.1
E3801.2	Allowable wiring methods	110.8 and 300.3(A)
Table E3801.2	Allowable wiring methods	None
E3801.3	Circuit conductors	300.3(B)
E3801.4	Wiring method applications	Chapter 3 and 300.2
Table E3801.4	Allowable applications for wiring methods	Chapter 3 and 300.2
SECTION E3802	ABOVE-GROUND INSTALLATION REQUIREMENTS	
E3802.1	Installation and support requirements	Chapter 3
Table E3802.1	General installation and support requirements for wiring methods	Chapter 3
E3802.2	Cables in accessible attics	320.23 and 334.23
E3802.2.1	Across structural members	320.23(A) and 334.23
E3802.2.2	Cable installed through or parallel to framing members	320.23(B)
E3802.3	Exposed cable	320.15 and 334.15
E3802.3.1	Surface installation	334.15(A)
E3802.3.2	Protection from physical damage	334.15(B)
E3802.3.3	Locations exposed to direct sunlight	310.10(D)
E3802.4	In unfinished basements	334.15(C)
E3802.5	Bends	334.24 and 338.24
E3802.6	Raceways exposed to different temperatures	300.7(A)
E3802.7	Raceways in wet locations above grade	300.9

SECTION E3803

UNDERGROUND INSTALLATION REQUIREMENTS

E3803.1	Minimum cover requirements	300.5(A)
Table E3803.1	Minimum cover requirements, burial in inches	Table 300.5
E3803.2	Warning ribbon.	300.5(D)(3)
E3803.3	Protection from damage	300.5(D)
E3803.4	Splices and taps	300.5(E)
E3803.5	Backfill	300.5(F)
E3803.6	Raceway seals.	300.5(G)
E3803.7	Bushing.	300.5(H)
E3803.8	Single conductors	300.5(I)
E3803.9	Ground movement	300.5(J)
E3803.10	Wet locations	300.5(B)
E3803.11	Under buildings	300.5(C)

CHAPTER 39

POWER AND LIGHTING DISTRIBUTION

SECTION E3901

RECEPTACLE OUTLETS

E3901.1	General	210.50 and 210.52
E3901.2	General-purpose receptacle distribution.	210.52(A)
E3901.2.1	Spacing	210.52(A)(2)
E3902.2.2	Wall space.	210.52(A)(2)
E3901.2.3	Floor receptacles.	210.52(A)(3)
E3901.2.4	Countertop receptacles	210.52(A)(4)
E3901.3	Small appliance receptacles	210.52(B)(1)
E3901.3.1	Other outlets prohibited	210.52(B)(2)
E3901.3.2	Limitations	210.52(B)(3)
E3901.4	Countertop receptacles	210.52(C)
E3901.4.1	Wall counter space	210.52(C)(1)
E3901.4.2	Island counter spaces	210.52(C)(2)
E3901.4.3	Peninsular counter space	210.52(C)(3)
E3901.4.4	Separate spaces.	210.52(C)(4)
E3901.4.5	Receptacle outlet location.	210.52(C)(5)
E3901.5	Appliance receptacle outlets.	210.50(C)
E3901.6	Bathroom	210.52(D) and 406.5(E)
E3901.7	Outdoor outlets.	210.52(E)
E3901.8	Laundry areas	210.52(F)
E3901.9	Basements and garages.	210.52(G)
E3901.10	Hallways	210.52(H)
E3901.11	Foyers	210.52(I)
	HVAC outlet.	210.63

SECTION E3902

GROUND-FAULT AND ARC-FAULT CIRCUIT-INTERRUPTER PROTECTION

E3902.1	Bathroom receptacles	210.8(A)(1)
E3902.2	Garage and accessory building receptacles	210.8(A)(2)
E3902.3	Outdoor receptacles	210.8(A)(3)
E3902.4	Crawl space receptacles	210.8(A)(4)
E3902.5	Unfinished basement receptacles	210.8(A)(5)

E3902.6	Kitchen receptacles	210.8(A)(6)
E3902.7	Sink receptacles	210.8(A)(7) and 406.5(E)
E3902.8	Boathouse receptacles	210.8(A)(8)
E3902.9	Boat hoists	210.8(C)
E3902.10	Electrically heated floors	424.44(G)
E3902.11	Location of ground-fault circuit interrupters	210.8
E3902.12	Arc-fault circuit-interrupter protection	210.12(A)
E3902.13	Arc-fault circuit-interrupter protection for branch-circuit extensions or modifications	210.12(B)

SECTION E3903**LIGHTING OUTLETS**

E3903.1	General	210.70(A)
E3903.2	Habitable rooms	210.70(A)(1)
E3903.3	Additional locations	210.70(A)(2)
E3903.4	Storage or equipment spaces	210.70(A)(3)

SECTION E3904**GENERAL INSTALLATION REQUIREMENTS**

E3904.1	Electrical continuity of metal raceways and enclosures	300.10
E3904.2	Mechanical continuity—raceways and cables	300.12
E3904.3	Securing and supporting	300.11(A)
E3904.3.1	Prohibited means of support	300.11(C)
E3904.4	Raceways as means of support	300.11(B)
E3904.5	Raceway installations	300.18
E3904.6	Conduit and tubing fill	300.17; Chapter 9, Table 1; and Annex C
Tables E3904.6(1)–		
E3904.6(10)	Maximum number of conductors in conduit or tubing	300.17; and Chapter 9, Table 1, Note 1
E3904.7	Air handling—stud cavity and joist spaces	300.22(C), Exception

CHAPTER E3905**BOXES, CONDUIT BODIES AND FITTINGS**

E3905.1	Box, conduit body or fitting—where required	300.15
E3905.1.1	Equipment	300.15(B)
E3905.1.2	Protection	300.15(C)
E3905.1.3	Integral enclosure	300.15(E)
E3905.1.4	Fitting	300.15(F)
E3905.1.5	Buried conductors	300.15(G)
E3905.1.6	Luminaires	300.15(J)
E3905.2	Metal boxes	314.4
E3905.3	Nonmetallic boxes	314.3
E3905.3.1	Nonmetallic-sheathed cable and nonmetallic boxes	314.17(C)
E3905.3.2	Securing to box	314.17(C)
E3905.3.3	Conductor rating	314.17(C)
E3905.4	Minimum depth of outlet boxes	314.24
E3905.4.1	Outlet boxes without enclosed devices	
E3905.4.2	Utilization equipment	
E3905.5	Boxes enclosing flush-mounted devices	314.19
E3905.6	Boxes at luminaire (lighting fixture) outlets	314.27(A)(1) and(2)
E3905.6.1	Wall outlets	
E3905.6.2	Ceiling outlets	

APPENDIX Q

E3905.7	Floor boxes	314.27(C)
E3905.8	Boxes at fan outlets.	314.27(D)
E3905.9	Utilization equipment	314.27(E)
E3905.10	Conduit bodies, junction, pull and outlet boxes to be accessible	314.29
E3905.11	Damp or wet locations	314.15
E3905.12	Number of conductors in outlet, device, and junction boxes and conduit boxes	314.16
E3905.12.1	Box volume calculations	314.16(A)
Table E3905.12.1	Maximum number of conductors in metal boxes	Table 314.16
E3905.12.1.1	Standard boxes	314.16(A)(1)
E3905.12.1.2	Other boxes.	314.16(A)(2)
E3905.12.2	Box fill calculations	314.16(B)
E3905.12.2.1	Conductor fill	Table 314.16 and 314.16(B)(1)
Table E3905.12.2.1	Volume allowance required per conductor.	Table 314.16(B)
E3905.12.2.2	Clamp fill	314.16(B)(2)
E3905.12.2.3	Support fittings fill	314.16(B)(3)
E3905.12.2.4	Device or equipment fill.	314.16(B)(4)
E3905.12.2.5	Equipment grounding conductor fill.	314.16(B)(5)
E3905.12.3	Conduit bodies	314.16(C)(1)
E3905.12.3.1	Splices, taps or devices.	314.16(C)(2)
E3905.12.3.2	Short radius conduit bodies	314.16(C)(3)

SECTION E3906

INSTALLATION OF BOXES, CONDUIT BODIES AND FITTINGS

E3906.1	Conductors entering boxes, conduit bodies or fittings	314.17
E3906.1.1	Insulated fittings	300.4(G)
E3906.2	Openings.	314.17(A)
E3906.3	Metal boxes, conduit bodies and fittings	314.17(B)
E3906.4	Unused openings.	110.12(A)
E3906.5	In wall or ceiling.	314.20
E3906.6	Noncombustible surfaces	314.21
E3906.7	Surface extensions	314.22
E3906.8	Supports	314.23
E3906.8.1	Surface mounting	314.23(A)
E3906.8.2	Structural mounting	314.23(B)
E3906.8.2.1	Nails and screws	314.23(B)(1)
E3906.8.2.2	Braces	314.23(B)(2)
E3906.8.3	Mounting in finished surfaces	314.23(C)
E3906.8.4	Raceway supported enclosures without devices or fixtures	314.23(E)
E3906.8.5	Raceway supported enclosures with devices or fixtures	314.23(F)
E3906.8.6	Enclosures in concrete or masonry.	314.23(G)
E3906.9	Covers and canopies	314.25
E3906.10	Metal covers and plates	314.25(A)
E3906.11	Exposed combustible finish	314.25(B)

SECTION E3907

CABINETS AND PANELBOARDS

E3907.1	Switch and overcurrent device enclosures	312.8
E3907.2	Damp or wet locations	312.2

E3907.3 Position in wall 312.3
 E3907.4 Repairing noncombustible surfaces 312.4
 E3907.5 Unused openings. 110.12(A) and 408.7
 E3907.6 Conductors entering cabinets 300.4(G) and 312.5(B)
 E3907.7 Openings to be closed. 312.5(A)
 E3907.8 Cables 312.5(C)

SECTION E3908

GROUNDING

E3908.1 Metal enclosures 250.86
 E3908.2 Equipment fastened in place or connected by permanent wiring methods (fixed) 250.110(1), (2) and (3)
 E3908.3 Specific equipment fastened in place or connected by permanent wiring methods 250.112(J), (L) and (M)
 E3908.4 Effective ground-fault current path 250.4(A)(5)
 E3908.5 Earth as a ground-fault current path 250.4(A)(5)
 E3908.6 Load-side grounded conductor 250.24(A)(5)
 E3908.7 Load-side equipment 250.142(B)
 E3908.8 Types of equipment grounding conductors 250.118
 E3908.8.1 Flexible metal conduit 250.118(5)
 E3908.8.2 Liquid-tight flexible metal conduit 250.118(6)
 E3908.8.3 Nonmetallic sheathed cable (Type NM). 334.108
 E3908.9 Equipment fastened in place or connected by permanent wiring methods 250.134
 E3908.10 Methods of equipment grounding. 250 Part (VII)
 E3908.11 Equipment grounding conductor installation 250.120
 E3908.12 Equipment grounding conductor size 250.122(A) and (B)
 Table E3908.12 Equipment grounding conductor sizing Table 250.122
 E3908.12.1 Multiple circuits 250.122(C)
 E3908.13 Continuity and attachment of equipment grounding conductors to boxes 250.148
 E3908.14 Connecting receptacle grounding terminal to box 250.146(A), (B) and (C)
 E3908.15 Metal boxes. 250.8 and 250.148(C)
 E3908.16 Nonmetallic boxes 250.148(D)
 E3908.17 Clean surfaces. 250.12
 E3908.18 Bonding other enclosures 250.96(A)
 E3908.19 Size of equipment bonding jumper on load side of service 250.102(D) and 250.122
 E3908.20 Installation—equipment bonding jumper. 250.102(E)
 E3908.20.1 Inside raceway or enclosure
 E3908.20.2 Outside raceway or enclosure.
 E3908.20.3 Protection

SECTION E3909

FLEXIBLE CORDS

E3909.1 Where permitted 400.7 and 400.8
 E3909.2 Loading and protection. 240.4; 240.5(A) and 240.5(B)(1); 400.5; and 400.13
 Table E3909.2 Maximum ampere load for flexible cords Table 400.5(A)(1)
 E3909.3 Splices. 400.9
 E3909.4 Attachment plugs 400.7(B)

CHAPTER 40
SECTION E4001

E4001.1	Rating and application of snap switches	404.14(A)
E4001.2	CO/ALR snap switches	404.14(C)
E4001.3	Indicating	404.7
E4001.4	Time switches and similar devices	404.5
E4001.5	Grounding of enclosures	404.12
E4001.6	Access	404.8(A)
E4001.7	Damp or wet locations	404.4
E4001.8	Grounded conductors	404.2(B)
E4001.9	Switch connections	404.2(A)
E4001.10	Box mounted	404.10(B)
E4001.11	Snap switch faceplates	404.9(A)
E4001.11.1	Faceplate grounding	404.9(B)
E4001.12	Dimmer switches	404.14(E)
E4001.13	Multipole snap switches	404.8(C)
E4001.14	Cord- and plug-connected loads	401.14(F)
E4001.15	Switches controlling lighting loads	404.2(C)

SECTION E4002

E4002.1	Rating and type	406.3(A) and (B)
E4002.1.1	Single receptacle	210.21(B)(1)
E4002.1.2	Two or more receptacles	210.21(B)(3)
Table E4002.1.2	Receptacle ratings for various size multioutlet circuits	Table 210.21(B)(3)
E4002.2	Grounding type	406.4(A)
E4002.3	CO/ALR receptacles	406.3(C)
E4002.4	Faceplates	406.6(B)
E4002.5	Position of receptacle faces	406.5(D) and 406.6
E4002.6	Receptacles mounted in boxes	406.5(A) and 406.5(B)
E4002.7	Receptacles mounted on covers	406.5(C)
E4002.8	Damp locations	406.9(A)
E4002.9	15- and 20-ampere receptacles in wet locations	406.9(B)(1)
E4002.10	Other receptacles in wet locations	406.9(B)(2)
E4002.11	Bathtub and shower space	406.9(C)
E4002.12	Flush mounting with faceplate	406.9(E)
E4002.13	Exposed terminals	406.5(F)
E4002.14	Tamper-resistant receptacles	406.12

SECTION E4003

E4003.1	Energized parts	410.5
E4003.2	Luminaires near combustible material	410.11
E4003.3	Exposed conductive parts	410.42(A)
E4003.4	Screw-shell type	410.90
E4003.5	Recessed incandescent luminaires	410.115(C)
E4003.6	Thermal protection	410.130(E)(1)
E4003.7	High-intensity discharge luminaires	410.130(F)

DEVICES AND LIGHTING FIXTURES
SWITCHES

RECEPTACLES

LUMINAIRES

E4003.8	Metal halide lamp containment	410.130(F)(5)
E4003.9	Wet or damp locations	410.10(A)
E4003.10	Lampholders in wet or damp locations.	410.96
E4003.11	Bathtub and shower area.	410.10(D)
E4003.12	Luminaires in clothes closets	410.2; and 410.16(A), (B), (C) and (D)
Figure E4003.12	Closet storage space	Figure 410.2
E4003.13	Luminaire wiring—general	410.48
E4003.13.1	Polarization of luminaires.	410.50
E4003.13.2	Luminaires as raceways	410.64(A), (B) and (C)
SECTION E4004	LUMINAIRE INSTALLATION	
E4004.1	Outlet box covers	410.22
E4004.2	Combustible material at outlet boxes	410.23
E4004.3	Access	410.8
E4004.4	Supports	410.30(A)
E4004.5	Means of support	410.36(A)
E4004.6	Exposed components	410.136(A)
E4004.7	Combustible low-density cellulose fiberboard.	410.136(B)
E4004.8	Recessed luminaire clearance.	410.116(A)(1) and (2)
E4004.9	Recessed luminaire installation	410.116(B)
SECTION E4005	TRACK LIGHTING	
E4005.1	Installation	410.151(A) and (B)
E4005.2	Fittings	410.151(A) and (D)
E4005.3	Connected load	410.151(B)
E4005.4	Prohibited locations	410.151(C)
E4005.5	Fastening.	410.154
E4005.6	Grounding.	410.155(B)
CHAPTER 41	APPLIANCE INSTALLATION	
SECTION E4101	GENERAL	
E4101.1	Scope	422.1 and 424.1
E4101.2	Installation	110.3(B) and 422.17
E4101.3	Flexible cords	422.16
Table E4101.3	Flexible cord length	422.16(B)(1), (2) and (4)
E4101.4	Overcurrent protection	422.11
E4101.4.1	Single nonmotor-operated appliance	422.11(E)
E4101.5	Disconnecting means	422.30, 422.35 and 424.19
Table E4101.5	Disconnecting means	422.31(A), (B) and (C); 422.34; 422.35; 424.19; 424.20; and 440.14
E4101.6	Support of ceiling-suspended paddle fans	422.18
E4101.7	Snow-melting and deicing equipment protection.	210.8(A)(3), Exception; and 426.28
CHAPTER 42	SWIMMING POOLS	
SECTION E4201	GENERAL	
E4201.1	Scope	680.1
E4201.2	Definitions	680.2

SECTION E4202

**WIRING METHODS FOR POOLS, SPAS,
HOT TUBS AND HYDROMASSAGE BATH TUBS**

E4202.1 General 680.7; 680.21(A); 680.23(B) and (F); 680.25(A);
680.40; 680.42; 680.43; and 680.70

E4202.2 Flexible cords . . 680.7(A) and (B); 680.22(B)(5); 680.23(B)(3); 680.42; and 680.43, Exception

E4202.3 Double-insulated pool pumps 680.21(B)

SECTION E4203

EQUIPMENT LOCATION AND CLEARANCES

E4203.1 Receptacle outlets 680.22(A)(5)

E4203.1.1 Location 680.22(A)(1)

E4203.1.2 Where required 680.22.(A)(3)

E4203.1.3 GFCI protection 680.22(C)

E4203.1.4 Indoor locations 680.43(A) and (A)(1)

E4203.1.5 Indoor GFCI protection 680.43(A)(2)

E4203.2 Switching devices 680.22(D), 680.43(C) and 680.72

E4203.3 Disconnecting means 680.12

E4203.4 Luminaires and ceiling fans 680.22(B)

E4203.4.1 Outdoor location 680.22(B)(1)

E4203.4.2 Indoor location 680.22(B)(2)

E4203.4.3 Existing lighting outlets and luminaires 680.22(B)(3)

E4203.4.4 Indoor spas and hot tubs 680.43(B)

E4203.4.5 GFCI protection in adjacent areas 680.22(B)(4)

4203.5 Other outlets 680.22(D)

E4203.6 Overhead conductor clearances 680.8

Table E4203.6 Overhead conductor clearances Table 680.8

E4203.7 Underground wiring 680.10

Table E4203.7 Underground wiring Table 680.10

SECTION E4204

BONDING

E4204.1 Performance 680.26(A)

E4204.2 Bonded parts 680.26(B); 680.26(E); 680.42(B); and 680.43(D)(4)

E4204.3 Pool water 680.26(C)

E4204.4 Bonding of outdoor hot tubs and spas 680.42 and 680.42(B)

E4204.5 Bonding of indoor hot tubs and spas 680.43(D)

E4204.5.1 Methods 680.43(E)

E4204.5.2 Connections 680.26(B)

SECTION E4205

GROUNDING

E4205.1 Equipment to be grounded 680.6

E4205.2 Luminaires and related equipment 680.23(F)(2) and 680.24(F)

E4205.3 Nonmetallic conduit 680.23(B)(2)(b)

E4205.4 Flexible cords 680.23(B)(3)

E4205.5 Motors 680.21(A)(1) and (4)

E4205.6 Feeders 680.25(B) and (B)(1)

E4205.6.1 Separate buildings 680.25(B)(2)

E4205.7 Cord-connected equipment 680.7

E4205.8 Other equipment Article 250, Parts V, VI and VII; and 680.6

SECTION E4206**EQUIPMENT INSTALLATION**

E4206.1	Transformers	680.23(A)(2)
E4206.2	Ground-fault circuit-interrupters	680.5
E4206.3	Wiring on load side of ground-fault circuit-interrupters and transformers	680.23(F)(3)
E4206.4	Underwater luminaires	680.23(A)(1), (3) and (7)
E4206.4.1	Maximum voltage	680.23(A)(4)
E4206.4.2	Luminaire location	680.23(A)(5) and (6)
E4206.5	Wet-niche luminaires	680.23(B)(1), (2), (4) and (5)
E4206.5.1	Servicing	680.23(B)(6)
E4206.6	Dry-niche luminaires	680.23(C)(1) and (2)
E4206.7	No-niche luminaires	680.23(D)
E4206.8	Through-wall lighting assembly	680.23(E)
E4206.9	Junction boxes and enclosures for transformers or ground-fault circuit-interrupters	680.24(A) through (E)
E4206.9.1	Junction boxes	680.24(A)(1) and (2)
E4206.9.2	Other enclosures	680.24(B)(1) and (2)
E4206.9.3	Protection of junction boxes and enclosures	680.24(C)
E4206.9.4	Grounding terminals	680.24(D)
E4206.9.5	Strain relief	680.24(E)
E4206.10	Underwater audio equipment	680.27(A)
E4206.10.1	Speakers	680.27(A)(1)
E4206.10.2	Wiring methods	680.27(A)(2)
E4206.10.3	Forming shell and metal screen	680.27(A)(3)
E4206.11	Electrically operated pool covers	680.27(B)(1) and (2)
E4206.12	Electric pool water heaters	680.9
E4206.13	Pool area heating	680.27(C)
E4206.13.1	Unit heaters	680.27(C)(1)
E4206.13.2	Permanently wired radiant heaters	680.27(C)(2)
E4206.13.3	Radiant heating cables prohibited	680.27(C)(3)

SECTION E4207**STORABLE SWIMMING POOLS**

E4207.1	Pumps	680.31
E4207.2	Ground-fault circuit-interrupters required	680.32
E4207.3	Luminaires	680.33
E4207.3.1	Within the low voltage contact limit	680.33(A)
E4207.3.2	Over the low voltage contact limit	680.33(B)
E4207.4	Receptacle locations	680.34

SECTION E4208**SPAS AND HOT TUBS**

E4208.1	Ground-fault circuit-interrupters	680.44(A) and (B)
E4208.2	Electric water heaters	680.9
E4208.3	Underwater audio equipment	680.43(G)
E4208.4	Emergency switch for spas and hot tubs	680.41

SECTION E4209

- E4209.1
- E4209.2
- E4209.3
- E4209.4

CHAPTER 43

SECTION E4301

- E4301.1
- E4301.2

SECTION E4302

- E4302.1
- E4302.2

SECTION E4303

- E4303.1
- E4303.2
- Table E4303.2
- E4303.2.1
- E4303.2.2
- E4303.2.3
- E4303.2.4

SECTION E4304

- E4304.1
- E4304.2
- E4304.3
- E4304.4
- E4304.5
- E4304.6

HYDROMASSAGE BATHTUBS

- Ground-fault circuit-interrupters 680.71
- Other electric equipment 680.72
- Accessibility 680.73
- Bonding 680.74

CLASS 2 REMOTE-CONTROL, SIGNALING AND POWER-LIMITED CIRCUITS

GENERAL

- Scope 725.1
- Definitions Article 100 and 725.2

POWER SOURCES

- Power sources for Class 2 circuits 725.121(A)
- Interconnection of power sources 725.121(B)

WIRING METHODS

- Wiring methods on supply side of Class 2 power source 725.127
- Wiring methods and materials on load side of Class 2 power source 725.130, 725.154, Table 725.154(G), 725.179
- Cable uses and permitted substitutions 725.154 and Table 725.154(G)
- Type CL2P cables 725.154(A) and 725.179(A)
- Type CL2 cables 725.179(C)
- Type CL2X cables 725.154(E)(4) and 725.179(D)
- Marking 725.179(L)

INSTALLATION REQUIREMENTS

- Separation from other conductors 725.136(A), (B), (C) and (D)
- Other applications 725.136(I)
- Class 2 circuits with communication circuits 725.139(D)
- Class 2 cables with other circuit cables 725.139(E)(1) through (5)
- Installation of conductors and cables 300.11(B)(2), 725.21, 725.24 and 725.143
- Bushing 725.3(J)