

Thank you for helping the City of Seattle address supply needs for COVID-19.

***The following packet provides the
following information:***

1. Manufacturing Specs

***2. Photos of Example
Reusable Cloth Face
Coverings***

3. Recommended Designs

4. Box Labeling Requirements

Cloth Reusable Face Coverings Specification

CDC

Follow the [Center for Disease Control Guidelines](#). We recommend your face covering design is in line with or a slight variation on the following patterns from [Kaiser Permanente](#) and [Olson by Unity Point Health/Made @ Generate](#) (see pages 4-13).

FABRIC TYPE	FABRIC COLOR	2 RECOMMENDED DESIGNS
<ul style="list-style-type: none">+ Fabric should be stable for machine or hand washing as per the CDC guidelines for washing face coverings.+ Recommend fabric be washed pre-production to reduce shrinkage.	<ul style="list-style-type: none">+ Neutral, solid colors <i>preferred</i> <p>TIES</p> <ul style="list-style-type: none">+ Can be ties around the head or elastic for around the ears on both designs	<ul style="list-style-type: none">+ Kaiser Permanente+ Olson

Examples of cloth Face Coverings of multiple patterns





7 1/2"
Care Label: Set in binding 3/8" from bottom edge

15 1/2"

1 1/2"
1 1/2"
1"
1 1/2"

7/8"





Finished Kaiser Permanente Face Coverings with ties behind the head





Olson Mask

Made by: Clayton Skousen & Rose Hedges


Materials Needed



- Cotton Weave Fabric (~1/2 yard is enough to make 2-3 masks)
- All-Purpose Thread
- Hair Ties (2)
- 0.3 micron Filter
- Scissors
- Double-Sided Skin Adhesive

Instructions

1 Using the patterns, cut one of each shape. You will need six (6) total pieces.



3 Sew *mouth 1* and *mouth 2* together along *side 3*.



2 Sew *face 1* and *face 2* together along *side 3*.



4 On *mouth 1* and *mouth 2* sew fold *side 5* over 1/4 inch and sew down..



Instructions - continued

- 5 On *cheek 1* and *cheek 2* fold *side 6* over 1/4 inch and sew down.



- 6 Match *cheek 1* and *mouth 1* at the dotted line (7). Sew a 1-inch tack at *side 1* and *side 2* where the two pieces overlap.



- 7 Repeat Step 6 for *cheek 2* and *mouth 2*.

- 8 With the fronts of the fabric facing each other, sew along the entire perimeter of the mask.



- 9 Use one of the slits between the mouth and the cheek to turn the mask ride-side out.



Instructions - continued

- 10 Add a hair tie to each side by folding the fabric on the end of the mask over the tie and sew down.



- 11 Apply double-sided skin tape around the contour of the mask to create the required seal.





Additional Instructions


*Elastic will be applied at the hospital, to allow for different sizes to be made.

** for those making for yourself or other hospitals we are using 0.3 micron filters and inserting them in the pocket. We are also using wax coated string at the top for the mask to create bridge, allowing a better seal**


Olson Mask - Mouth & Cheek Pattern





Olson Mask - Face Pattern



Olson Mask - Face Pattern



Olson Mask - Mouth & Cheek Pattern



Packaging / Packing

- + Please confirm packaging and case pack instructions directly with the buyer.
- + Sticker (ASE255) to be applied to outside of each package or to the carton with the following text:
- + For example, if you have boxes inside a larger box, each box must have the label. If you only have one big shipping box with the masks inside, the sticker must be somewhere on the outside or inside the packing.

For Reusable Face Coverings

FACE COVERINGS

NOT INTENDED FOR CLINICAL USE MUST
BE LAUNDERED BEFORE USE

Box Labeling Requirements

The following text must be visible on each box exterior. Select label option based on Coverings type.

For Reusable Face Coverings

FACE COVERINGS

NOT INTENDED FOR CLINICAL USE

MUST BE LAUNDERED BEFORE USE